

FIG. 1




FIG. 2

Operating key (Dial button)	Numeral input-mode	Alphabetic Kana-input Mode English letter Input-Mode
1	1	AB
2	2	KC
3	3	SD
4	4	TF
5	5	NG
6	6	HJ
7	7	ML
8	8	YP
9	9	RQ
0	0	WV
*		XZ

3/9

FIG. 3




FIG. 4





FIG. 5



4/9

FIG. 6




FIG. 7




FIG. 8




FIG. 9

Character-Input Button	Alphabetic Kana-input Mode Eng. letter-input mode
F1	A B
F2	I O
F3	U J
1	B 1 C
2	K 2 D
3	S 3 F
4	T 4 G
5	N 5 L
6	H 6 P
7	M 7 Q
8	Y 8 V
9	R 9 X
0	W 0 Z
*	` ° · ;

FIG. 10




FIG. 11




FIG. 12




FIG. 13

Dial Button	Kana-input mode	Eng. letter-input mode
1	あいうえおあいうえお	@
2	かきくけこ	ABCabc
3	さしすせそ	DEFdef
4	たちつてとっ	GHIghi
5	なにぬねの	JKLjkl
6	はひふへほ	MNOmno
7	まみむめも	PQRSpqrs
8	やゆよやゆよ	TUVtuv
9	らりるれろ	WXYZwxyz
0	わをん	